

Getting Started



2 Pair it




- Press the Power button on the keyboard. The blue LED light will glow for 2 seconds.
- Press and hold the Pair button on the keyboard <---> for 5 seconds until the keyboard blue light flashes again.
- Turn on Bluetooth[®] mode on your smartphone or tablet. Search

for new devices until your see "iwerkz Keyboard" listed. Press "iwerkz Keyboard" to pair with keyboard.

 Once paired, select your OS by pressing and holding the FN key, then press A (Android) or S (iOS).

3 Use it



Buttons and Indicators

Ф	ON/OFF Switch	
<> Connect	Device "CONNECT" Button	
((p)ြူ Status	Solid Blue (2 sec.)	Keyboard On
	Flashing Blue (slow)	Ready to Pair
	Flashing Blue (fast)	Keyboard Off
⅓ Charge	Glowing Red	Charging
	OFF	Fully Charged
	Flashing Red	Needing Charge



Waterproof Folding Bluetooth® Keyboard




The iwerkz Waterproof Folding Bluetooth® Keyboard is designed to work with most iOS and Android tablets and smartphones using Bluetooth® wireless technology. Please read this User Manual to get started.

What's Included:

- Keyboard
- · Case / Stand
- Charging Cable
- User Manual

Keyboard Shortcuts

To access keyboard shortcuts, press and hold the FN key while pressing the desired shortcut key. Remember that some keys are specific to either iOS or Android operating systems and may not work on all smartphones or tablets models and brands.



To set up the keyboard for iOS or Android specific operation, press and hold the FN key, then press either the Android (A) or iOS (S) key.



Troubleshooting

If the keyboard does not pair with your device:

- Panic
- Just kidding
- Check and verify that the keyboard is turned on and charged
- Check and verify that the Bluetooth[®] setting is active on your device

If the **keyboard was connecting perfectly**, then stopped working:

- Charge it overnight that often fixes minor connection and usage issues
- Unpair your keyboard and start the entire pairing process over
- Power off, then back on both your keyboard and your device and start the pair process again

If you are still having trouble with your keyboard, please visit www.mywerkz.com for support, FAQs and other tips.



Connect with us

Contact support@mywerkz.com for technical support, questions, warranty concerns and just about anything else that's on your mind.

We love to hear about concerns & feedback, hear your product suggestions and connect with you directly so that we can better serve your needs.



Get free stuff

Yes, it pays to read your User Manual all the way to the end. Sign up for our Product Review team and we'll send you free products when they're available.

We'll reach out to you when we have a new product ready to launch. You provide feedback and post your (hopefully good) review online. It's that simple. There are no obligations or expectations of anything other than honest reviews. See www.mywerkz.com for details.

All trade names are the registered trademarks of respective manufacturers listed.









This device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions:

- 1. This device may not cause harmful interference
- This device must accept any interference received, including interference that may cause undesired operation

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- -Reorient or relocate the receiving antenna.
- -Increase the separation between the equipment and receiver.
- -Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- -Consult the dealer or an experienced radio/TV technician for help.

Changes or modifications not authorized by the party responsible for compliance could void the user's authority to operate this product.

Limited 1 Year Warranty

Sela Products, LLC warrants this product at the time of sale to be free from manufacturing defects in materials and workmanship. Sela Products, LLC will replace this product for such defects within 1 year from the date of purchase to the original purchaser. Normal wear and tear are excluded from this warranty. There are no warranties which extend beyond the description on the face hereof.